


Desk Assembly - Watch Assembly Video here: <https://youtu.be/REizL86gvYo>

IMPORTANT NOTE: Plywood thickness is marked as .75in and 5.in in this drawing. In reality these will be less than these values. All the routed grooves must be cut to your board's nominal thickness.



If there are any issues with the drawings or design leave a comment on the YouTube Video. I want to know!